

STAR-TOUCH

# Mintaka

## INNOVATIONS

INNOVATORS OF PRECISION BAROGRAPHIC SYSTEMS

# MENU MAP

WELCOME

**Mintaka StarTouch**  
Welcome, Select Time Zone

UTC+0

3/11/25 1:54:18 UTC+0

OK

MAIN SCREENS


**T2222265 - Select View**

Graph Values StarX/G

GPS Comm Settings

In general, swipe up from the bottom of a screen to view the previous screen.

**Station Pressure**  
Sampling Interval: 24 minutes



873.7 ↑ Tend 0.7 mb  
TC ✓ (3)

3/26/25 9:51:21 UTC-7

**Station Pressure - mb**

868.3 →

Tend 0.2 mb TC ^ (0)

10/12/25 9:46:32 UTC-7

**StarXG+ H222222B**

864.2 mb -0.5 mb ✓ (5)  
15.6 C WB -99.9 C DP -99.9 C 30 %  
Lat --- Long ---  
Speed --- Course ---  
Battery 2.48 Volts Interval 0:05:00  
Age 0:06:59

4/01/25 10:21:14 UTC-7

**GPS Summary**

GPS Fix

Latitude 34 47.3898N  
Longitude 111 45.4225W  
Speed 0.6 Knots  
Course 139 T

**LoRa & WiFi Status**


LoRa Mode: On  
WiFi Mode: Access Point  
IP Addr: 192.168.4.1  
SSID:  
MintakaWx

**Settings**

About Display TZ

Barometer Settings

PRESSURE SETTINGS



### Select Plot Options

Sampling Interval

Range 23.2 Hours

Running Average

Swipe Right & Left to Change Sample Interval  
Swipe Down from Top to View Plot Options

SETTINGS

### Settings

### Mintaka StarTouch

Version 4.0.43

Serial# T222222F

### Display Parameters

Timeout:

Dim Level:

### Choose Time Zone

Time Zone

BAROMETER SETTINGS

### Barometer Settings

### Settings Access

Enter WxService PIN

Enter PIN

When in WxService Mode

### Set Date/Time

Set Date

Set Time

### Select Units

Pressure

Elevation

Speed

### Set Sealevel Pressure

Adjust Using

To  Feet

### Set Pressure Offset

Sensor

Offset By

To Read

### System Setting

SYSTEM SETTINGS

### Reset StarTouch

Choose Reset Type:

### WxService Mode is On

Disable WxService Mode

Enter PIN